

CALC free

Highly efficient descaler

High performing | Polyvalent | Fast action



Technical Information

Product profile

- CALC free removes effectively lime scale deposits from dishes, utensils and surfaces as well as oily residues in dishwashers.
- Thanks to its outstanding performance, CALC free saves costs and time and allows a longer lifespan of machines.
- CALC free prevents corrosion and causes very low foaming.

Area of application

- Suitable for all acid-prooved dishwashers and washing machines.
- To descale equipment: Use a 2-10% diluted solution. Let it work between 15 and 20 min (it is recommended to switch the machine on). Drain and rinse off with clear water.
- To descale washing machines: Diluted – Before descaling the dishwasher switch off detergent dispenser. Dose at 2-10%. Switch on the empty (or filled) dishwasher and let it work for 15 to 20 min, then drain and rinse off.

A complete washing cycle (cleaning + rinse) is to be run to descale the dishes.

- Concentrated – Pour CALC free on and leave to work. After descaling drain off and rinse with clear water.

Ingredients, handling, storage and environmental instructions

For the ingredients list, please see the Safety Data Sheet. Product strictly reserved for a professional use. For all information regarding handling, storage conditions and disposal, please see the Safety Data Sheet.

Sales units:

712688 - 10 x 1 l

712686 - 2 x 5 l

713238 - 1 x 10 l

Company certificates of Management Systems




pH value 1%



Application and Dosing



Dose in relation to application and degree of water hardness. Follow below instructions.



Scale prevention:


Prevents scaling of the heating elements.



200-500 ml/l

Spray cleaning:

Spray directly or onto a suitable cloth. Allow short action time and wipe with clean cloth.



20-100 ml/l

Mechanical use:

Suitable for all types of dishwashing machines.



Put the dishes in an upright position and let them drip dry.